

Figure 1: Finger core with wire channel.

Finger Construction Steps
E.J. Nicolson

In this procedure, "Upper mask" refers to a piece of copper which has been photomasked with the resist pattern for the upper electrodes and "lower mask" refers to the piece masked for the lower electrodes. Figure 1 shows the sensor core and sense strips with the groove (wire channel) for the 8 conductor wire.

1. Prepare core
   (a) Choose radii r_a and r_b and sampling density.
   (b) Cut stock to length (32 mm final, 35 mm rough), lathe to desired radius, face ends (speed above 200, 3.0 inches/min).
   (c) Center drill, Drill # 7 hole, tap for 1/4-20 thread.
   (d) Cut 1/4-20 threaded rod stock.
2. Prepare mask
   (a) Paint nail polish onto back of mask.
   (b) Cut out bottom portion, leave about 0.25" copper at the end, cut sides close. Length should be $< 2\pi r_a$.
3. Attach lower mask
   (a) Glue mask to core using Devcon 5 minute epoxy. Be sure not to get any epoxy on front copper since it will act as a resist. This is most important in the sensing area, but not so important at

the ends. Sensing electrodes should be at the end opposite to the tapped end.

(b) Etch in Ferric Chloride. Add 25% hot (25 ml) (near boiling) water by volume to etching fluid to speed process. Swirl for about 20 minutes.

(c) Wash off in water. Let dry.

(d) Drill alignment hole. 1.6mm diameter $\simeq$ #52 approximately half way between center and outside. Err to the outside to leave enough room for the nut. The location is to the left side looking from the top with the front up. Drill Air escape holes , #29 drill, all the way through.

(e) Use the mill to cut channels for the wires. Turn on the monitor, turn on the mill power, turn on the air. Set up the vice with the pin in the third hole from the left. Insert the tool. Mount the sensor back facing up. Use manual control to find the approximate zero at 9in/min. Reduce the speed to 2in/min and take small z steps to find the correct height. Set the zero position from the Initialize menu. Load c:\ ed \ filename. Run. For new tool find new z origin.

When doing the front, mill a small cut in the center, front, and bottom end to use for alignment with center of the upper mask. Use the 0.025" tool. Be very careful since the tool breaks easily. To make the notch in the bottom end, jog .05" in x, .01" deeper in z each time at a speed of 1"/min.

Mill Programs, mount core with $x + ive$ = cylinder axis to top				
$r_a * 2$	Side	Program	Tool	Origin
22 mm	Back	BC1	5/32" flat end	center back, cable end
		BC2	1/16" flat end	center back, cable end
	Front	FC1	5/32" flat end	center front, cable end + 5/64"
19.5 mm	Back	FC1	5/32" flat end	center back, cable end
		BC2	1/16" flat end	center back, cable end
	Front	FC1	5/32" flat end	center front, cable end + 5/64"

(f) Repair strips by gluing with "superglue" any loose traces. Cut off any copper that was not properly etched.